


# Configure your mobile device

If you are unable to connect automatically to Singtel WiFi, you can configure your device by following these steps. To begin, select your device type.

Android Devices .....	1
Blackberry .....	4


## Android Devices

Step 1  
Select WiFi from settings menu.



Step 2


Tap Singtel WiFi SSID, then select the drop down menu under EAP method.





Step 3


Set SIM from the drop down menu and tap connect.



## Blackberry


### Step 1

Select WiFi from settings menu.



Step 2

Tap Singtel WiFi SSID, then select the drop down menu under EAP method.



Step 3

Select SIM from the drop down menu and tap connect.

